

08213

# AIRPORT DIAGRAM


BALTIMORE/WASHINGTON INTL THURGOOD MARSHALL (BWI)  
AL-804 (FAA)

BALTIMORE, MARYLAND

ATIS 115.1 127.8  
BALTIMORE TOWER  
119.4 257.8  
GND CON  
121.9  
CLNC DEL  
118.05

324  $\Delta$

39°12'N




JANUARY 2005  
ANNUAL RATE OF CHANGE  
0.0°W

Rwy 10 ldg 9952'  
Rwy 28 ldg 10002'

RWY 4-22  
S100, D220, ST175, DT500, DDT728  
RWY 10-28, 15R-33L  
S100, D220, ST175, DT500, DDT790  
RWY 15L-33R  
S30, D60

NE-3, 31 JUL 2008 to 28 AUG 2008

NE-3, 31 JUL 2008 to 28 AUG 2008



76°41'W

76°40'W

39°10'N

# AIRPORT DIAGRAM

BALTIMORE, MARYLAND

BALTIMORE/WASHINGTON INTL THURGOOD MARSHALL (BWI)

08213